



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set. Read this sheet and all instructions included with the different parts before assembly. See the Instructions and Owner's Manual included in carton 63067-202 for important safety information.

Dimensions of assembled package:
16' 9" wide x 16' 6" deep x 11' 6" tall

Cartons for this Play Set:

1	63062-211	Ridgefield 1 (Hardware)
1	63067-202	Ridgefield 2 (Instructions)
1	63006-421	Williamsburg Box 1 (Hardware)
1	63006-422	Williamsburg Box 2
1	63006-423	Williamsburg Box 3
1	63006-445	Williamsburg Roof (Hardware)
2	40456-402	End Panel Assembly
1	40457-402	Side Window Panel
1	40458-402	Door Panel (Hdwre & Instr)
1	SM964-402	Gable Fans (Hdwre & Instr)
1	SM963-402	Dormer (Hdwre & Instr)
1	SH946-102	Access Ladder 5ft.
1	63058-202	4 Position Swing Beam
1	63076-303	9 ft Beam Legs (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	8364-400	10 ft Scoop Slide



- Start by assembling the Ridgefield tower. Instructions are in carton 63067-202. Other instructions and hardware are in the cartons noted above. Do not use the Williamsburg instructions packed in the roof carton.
- Ridgefield step 18. The 7ft Beam will be mounted in the position pictured above, parallel to the roof. Drill the holes. Insert the weld nuts.
- Ridgefield step 33. Wait to install the wall slats.
- Install the swing beam using the holes drilled in step 18. Instructions are in carton 63076-303.
- Set the ladder and slide as shown above. Check spacing.
- Fasten access brackets to the **inside** of the ladder rails. Secure the access ladder using the method shown in step 36 of the Ridgefield instructions.
- Install the slide mount and slide using the method shown in steps 38 and 39 of the Ridgefield instructions
- Install the wall slats in the positions shown above, using the methods from the Ridgefield instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.