



Dimensions of assembled package:
40' wide x 25' deep x 12' 9" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-445 for important safety information.

Cartons for this Play Set:

| | | |
|---|------------|---------------------------------------|
| 1 | 63007-421 | Lexington Gym 1 (Hardware) |
| 1 | 63007-422 | Lexington Gym 2 |
| 1 | 63007-423 | Lexington Gym 3 |
| 1 | 63007-445 | Lexington Roof (Hdwre & Instr) |
| 2 | SH946-102 | Access Ladder, 5ft |
| 1 | 63006-421 | Williamsburg Box 1 (Hardware) |
| 1 | 63006-422 | Williamsburg Box 2 |
| 1 | 63006-423 | Williamsburg Box 3 |
| 1 | 63006-445 | Williamsburg Roof (Hdwre & Instr) |
| 1 | 63058-202 | 4 Position Swing Beam |
| 1 | 63060-222 | 9ft Swing Beam Legs (Hdwre & Instr) |
| 1 | 50546-777 | 3 Swings, 1 Trapeze |
| 1 | 63008-221 | Skybox 1 (Hdwre & Instr) |
| 1 | 63008-222 | Skybox 2 |
| 1 | SJ926-810 | Skybox Wood Roof (Hdwre & Instr) |
| 1 | 15166-400 | 10 ft. Super Wave Slide |
| 1 | AH201-102Q | Rock Climbing Wall (Hdwre & Instr) |
| 1 | 63079-102 | Monkey Bars (Hdwre & Instr) |
| 1 | 63081-102 | Ice Cream Stand (Hdwre & Instr) |
| 1 | SH922-800Q | Ramp (Hdwre & Instr) |
| 1 | SH304-101Q | Pinnacle Rock Wall (Hdwre & Instr) |
| 1 | 63073-101 | Clubhouse Window Pk (Hdwre & Instr) |
| 2 | 15140-400 | 14ft Rocket Slide & Foot |
| 1 | 50398-700 | Skybox Slide Kit (Hdwre & Instr) |
| 1 | 8400-202 | Spiral Slide, Green (Hardware) |
| 1 | 63091-111 | Direct Connect Adapt. (Hdwre & Instr) |
| 1 | SC910-800Q | Lexington Play Floor (Hdwre & Instr) |
| 1 | SC904-800Q | Skybox Play Floor (Hdwre & Instr) |
| 1 | SC908-800Q | Wmsbg Play Floor (Hdwre & Instr) |

| | | |
|---|------------|-------------------------------------|
| 1 | SD920-800Q | Wmsbg Picnic Table (Hdwre & Instr) |
| 1 | AP970-104 | Bubble Panel (Hdwre & Instr) |
| 2 | AG942-400 | Acc. Ladder Handles (Hdwre & Instr) |
| 3 | AG943-400 | Slide Handle (Hdwre & Instr) |
| 3 | SM964-402 | Gable Fans (Hdwre & Instr) |
| 3 | SM963-402 | Dormer (Hdwre & Instr) |
| 1 | SJ951-102 | Bridge (Hdwre & Instr) |
| 2 | 40456-402 | End Window Panel |
| 1 | 40459-402 | Double Window Panel |
| 1 | 40460-402 | Door & Window Panel (Hardware) |

- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted at left. Notice the **gym is rotated 90° from the position shown in the instructions**
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Wmsbg step 2. Do not install the Sandbox End on the end adjacent to the Skybox. It will be replaced when installing the play floors.
- Wmsbg step 11. You can install both the left and right wall supports here since one end wall support will not be used.
- Wmsbg step 14. Do not install the End Wall Support adjacent to the Skybox. It will not be needed.
- Skip Wmsbg steps 20 & 21.
- Once the roof, roof supports, and ridge cap are installed, proceed with the Skybox tower.
- Skybox step 2. Omit the sandbox end under the gym. The floor transition from the Skybox Play Floor will be used instead.



Williamsburg Tower

Lexington Tower

- Skybox step 11. Use the front posts from The Skybox Roof (SJ926-810) in place of the post extensions.
- Skybox Step 17. Wait to install the wall slats on the back and side where the pinnacle rock climber and slides will mount, until after installing the climber and slides.
- Skybox Step 21 & 22. Install the slats in reverse orientation so the opening is on the opposite side. Install the ladder aligned with the opening.
- Ignore the special instructions regarding mounting with play floors in the Skybox instructions. Install the Wmsburg Play Floor (SC908-800Q) and Skybox Play Floor (SC904-800Q) using the method shown on page three of the skybox play floor instructions titled "Install the Skybox Play Floor adjacent to a gym with a play floor."
- Once the basic Williamsburg-Skybox tower is assembled assemble the Lexington tower about 92" away from the Williamsburg.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the whole play set is complete.
- Lex step 7. Move the tower into place 92" from the other tower. Use the bridge rails from SJ951-102 to assure the alignment is exact. Continue assembly making sure the posts are plumb and the towers are level. (Note: the angle braces will be removed to fit the clubhouse panels in a future step.)
- Skip Lex step 20 & 21.
- After installing the roof, install the bridge between the towers using the instructions from SJ951-102.
- Install the swing beam. Instructions and hardware are in the 9' Swing Beam Leg Carton (63060-222).
- Mount the Rock Climbing Wall (AH201-102Q) to the front center of the Bridge.
- Mount the Bubble Panel (AP970-104) to the back center of the Bridge.
- Using a ladder, install three Dormers (SM963-402) in the positions shown on the front page. Ladder access may be obstructed by later installations.
- Install a Gable Fan (SM964-402) at each end of each roof.
- Install the Lexington Play Floor (SC910-800Q).
- Remove the Lexington angle braces. Mount the Window and Door Panels (40456-402, 40459-402, & 40460-402) in the Lexington tower as shown above.
- Mount an Access Ladder (SH946-102), Monkey Bars (63079-102), and Super Wave Slide (15166-400) to the front of the Lexington tower.
- Assemble the Spiral Slide (8400-202) and mount it to the End of the Lexington tower using the Direct Connect Adapter (63091-111).
- Assemble and mount the Pinnacle Rock Wall (SH304-101Q) to the front of the Skybox.
- Mount one Access Ladder (SH946-102) and the Ramp (SH922-800Q) to the front of the Williamsburg tower, arranged as shown on the front page of this guide.
- Mount two Handles (AG942-400) to each Access Ladder.
- Mount the Ice Cream Stand (63081-102) to the end of the Skybox.
- Install both Rocket Slides (15140-400) using Skybox Slide Kits (50398-700).
- Mount a Slide Handle (AG943-400) above the Super Wave Slide and both Rocket Slides.
- Install the wall slats in the positions shown above and on the first page, using the methods from the Williamsburg Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount the hand grips to the entrance wall slats.
- Install the Shutters and Flower Box from the Clubhouse Window Pack (63073-101) to the window panel below the Bridge.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.
- Hang the swings.