



Dimensions of assembled package:
14' 11" wide x 27' 0" deep x 12' 9" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63069-601 for important safety information.

Cartons for this Play Set:

1	63069-601	Manchester Box 1 (Instr & Hdwre)
1	63069-602	Manchester Box 2
1	63069-603	Manchester Box 3
1	63069-604	Manchester Box 4
1	63069-605	Manchester Box 5
1	63069-606	Manchester Box 6 (Hardware)
1	63069-707	Manchester Box 7
1	15168-400	Rocket Slide 12ft.
1	63058-202	4 Position Swing Beam
1	63076-303	9ft Beam Legs (Instr & Hdwre)
1	50546-777	3 Swings, 1 Trapeze
1	63079-102	Monkey Bars (Instr & Hdwre)
1	SM963-402	Dormer (Instr & Hdwre)
1	SM964-402	Gable Fans (Instr & Hdwre)
1	AG943-400	Slide Handle (Instr & Hdwre)
1	AG942-400	Access Handles (Instr & Hdwre)

- Assemble the Manchester tower as shown in the instructions in Manchester Box 1 (63069-601).
- Manchester step 39. Wait to install the front wall slats until after the slide & monkey bars are mounted.
- Install the Dormer (SM963-402) before the swing beam and slide for better ladder access.
- Install the swing beam using instructions from 63076-303 and step 46 in the Manchester manual. For proper fit within the play zone found in the Creative Playthings play zone book, install the swing mount to the corner post by the rung ladder.
- Install the Monkey Bars (63079-102) in the position shown. See the last page of the monkey bar instructions for mounting the monkey bars to the Manchester gym.
- Install the Rocket Slide as shown in the Manchester instructions.
- Install a single wall slat between the slide and monkey bars. Make sure all gaps are narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Install the Gable Fans (SM964-402).
- Install the Access Handles (AG942-400) on both sides of the steps.
- Mount the Slide Handle (AG942-400) above the slide.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.