



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63085-654 for important safety information.

Dimensions of assembled package:
11' 5" wide x 22' 0" deep x 10' 5" tall



Cartons for this Play Set:

1	63085-641	Northbridge Box 1 (Hardware)
1	63085-652	Northbridge Box 2
1	63085-603	Northbridge Box 3
1	63085-654	Northbridge Tent (Instructions)
1	63045-505	Tire Swing (Hardware)
1	8570-202	10ft. Wave Slide
1	63080-101	Classic Pine Beam (Hdwre & Instr)
1	AA934-204	2 Swings, 1 Ring Trapeze

- The instructions found in 63085-654 give a complete description for assembling all features of the play tower.
- After step 29 switch to the instructions included with the Swing Beam (63080-101). Install the swing beam.
- Once the beam is installed, continue assembling the tower.
- Upon completion check to assure all fasteners are secure.