## Creative Playthings

CHILDHOOD STARTS HERE

## NORTCP4 Northbridge Classic Pack 4

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63085-655 for important safety information.

## Cartons for this Play Set:

- 1 63085-641 Northbridge Box 1 (Hardware)
- 1 63085-652 Northbridge Box 2

Dimensions of assembled package:

11' 5" wide x 22' 0" deep x 10' 5" tall

- 1 63085-603 Northbridge Box 3
- 1 63085-655 Northbridge Wood Roof (Hdwre & Instr)
- 1 63045-505 Tire Swing (Hardware)
- 1 8570-202 10ft. Wave Slide
- 1 63080-101 Classic Pine Beam (Hdwre & Instr)
- 1 AA934-204 2 Swings, 1 Ring Trapeze
- 1 63082-102 Monkey Bar (Hdwre & Instr)

- Start assembly of the tower using the instructions found in 63085-655.
- After step 29 switch to the instructions included with the Swing Beam (63080-101). Install the swing beam.
- · Once the beam is installed, continue assembling the tower.
- · Step 35. Wait to install the wall slats until after installing the

monkey bar.

- Mount the Monkey Bar (63082-102) to the front of the tower in the position shown.
- Install the wall slats as shown above. Continue assembling the gym as shown in the tower instructions.
- · Upon completion check to assure all fasteners are secure.

NORTHBRIDGE CLASSIC PACK 4