

Dimensions of assembled package:
15' 6" wide x 20' 0" deep x 9' 10" tall



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 60082-451 for important safety information.

Cartons for this Play Set:

1	60082-451	Spring Hill (1 of 3) (Hdwre & Inst.)
1	60082-452	Spring Hill (2 of 3)
1	60082-453	Spring Hill (3 of 3)
1	8570-202	10' Wave Slide
1	60081-102	Playtime Swing Beam (Hdwre & Inst.)
1	AA934-204	2 Swings, 1 Ring Trapeze
1	AE914-412	Steering Wheel (Hdwre & Inst.)
1	AA935-302	Telephone (Hdwre & Inst.)
1	AE915-304	Telescope (Hdwre & Inst.)
1	AA911-50541	Glider & Econ. Brackets (Hdwre & Inst.)
1	60084-101	Monkey Bar (Hdwre & Inst.)



- The instructions found in 60082-451 give a complete description for assembling the play tower.
- On step 20 don't install the wall slats across the back of the tower. They will go in when installing the Monkey Bars.
- After step 33 assemble and mount the Monkey Bars using the instructions in box 60084-101.
- Next, use the instructions included with the Swing Beam (63080-101) and Glider Brackets (AA911-50541).
- Install the Glider Brackets on the Swing Beam. Do not install Swing Hangers below the Glider Brackets.
- Assemble the Swing Beam and mount it to the tower.
- After installing the beam and securing the ground stakes, check to assure all fasteners are secure.
- Install the Steering Wheel (AE914-412), Telephone (AA935-302), and Telescope (AE915-304) in the desired positions. Make sure none of them are placed in line with the exit of the slide or in line with the swings.
- Hang the swing, trapeze, and glider.