Creative Plaything/

CHILDHOOD STARTS

RIDGFSWPP

RIDGEFIELD PREMIUM PACK Clubhouse



Cartons for this Play Set:

1	63062-211	Ridgefield 1 (Hardware)
1	63067-202	Ridgefield 2 (Instructions)
1	63006-421	Williamsburg Box 1 (Hardware)
1	63006-422	Williamsburg Box 2
1	63006-423	Williamsburg Box 3
1	63006-445	Williamsburg Roof (Hardware)
2	40456-402	End Panel Assembly
1	40457-402	Side Window Panel
1	40458-402	Door Panel (Hdwre & Instr)
1	SM964-402	Gable End Fan Brown (Hdwre & Instr)
1	SM963-402	Dormer Brown (Hdwre & Instr)
1	SH946-102	Access Ladder 5ft.
1	8364-400	10 ft Scoop Slide
1	AG942-400	Access Ladder Handles (Hdwre & Instr)
1	AG943-400	Slide Handle (Hdwre & Instr)
1	SC907-800Q	Williamsburg Play Walls (Hdwre & Instr)
1	SC908-800Q	Williamsburg Play Floor (Hdwre & Instr)
1	63071-101	Ridgefield Play Walls (Hdwre & Instr)
1	63072-101	Ridgefield Play Floor (Hdwre & Instr)
1	63081-102	Ice Cream Stand (Hdwre & Instr)
1	AA918-603	Chin-up bar (Hdwre & Instr)
1	63090-222	Chain Climber Frame (Hdwre & Instr)
1	63089-606	Chain Cargo Net

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly. See the Instructions and Owner's Manual included in carton 63067-202 for important safety information.

- Start by assembling the Ridgefield tower. Instructions are Set the access ladder and slide as shown. Check spacing. in carton 63067-202. Other instructions and hardware are in the cartons noted at left. Do not use the Williamsburg instructions packed in the wood roof carton.
- Wait to install the Access Ladder, Slide, and Wall Slats until Fasten the Access Ladder Handles (AG942-400) to the Acafter the rest of the play set is complete.
- Ridgefield step 12: do not install the angle brace where the chalkboard from the icecream stand will mount.
- Install the Porch Play Floor (63072-101) and Williamsburg Play Floor (SC908-800Q). Use 3" bolts included with the porch floor to install adjacent floor cleats as mentioned in step 2 of the porch floor instructions.
- · Install the Ice Cream Stand (63081-102) in the position shown.
- Install the Play Walls (SC907-800Q) across the back of the main tower and along the side opposite the ice cream stand.
- Install the Porch Play Walls (63071-101) across the front and along the side of the main tower as shown above.
- Mount the Chain Climber to the side of the porch opposite the ice cream stand using the instructions included in . 63090-222.

- Fasten access brackets to the inside of the ladder rails. Secure the access ladder using the method shown in step 36 of the Ridgefield instructions.
- cess Ladder.
- Install the slide mount and slide using the method shown in steps 38 and 39 of the Ridgefield instructions.
- Mount the Slide Handle (AG943-400) above the slide.
- Install the wall slats to the main tower in the postions shown in this installation guide using the methods from the Ridgefield. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Mount the Chin-up Bar (AA918-603) to the post adjacent to the access ladder.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.

RIDGEFIELD PREMIUM PACK CLUBHOUSE