Creative Plaything/®

WILL7TPP2 Williamsburg Premium Pack 2

CHILDHOOD STARTS HERE

Cartons for this Play Set:

1

- 1 63006-421 Williamsburg Box 1 (Hardware)
- 63006-422 Williamsburg Box 2
- 63006-423 Williamsburg Box 3
- 63006-424 Williamsburg Tent (Hdwre & Instr)
- SH946-102 Access Ladder, 5ft
- 63058-202 4 Position Swing Beam
- 1 63059-212 7ft Swing Beam Legs (Hdwre & Instr)
 - 31820-102 Swing Mount
 - 50546-777 3 Swings, 1 Trapeze
 - 8364-400 10 ft Scoop Slide, Green
 - SD920-800Q Wmsbg Picnic Table (Hdwre & Instr)
- 1 AH201-102Q Rock Climbing Wall (Hdwre & Instr)

Dimensions of assembled package: 19' 8" wide x 14' 6" deep x 10' 7" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-424 for important safety information.

- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted above right.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- On step 19 be sure to install the swing mount on the side shown above.
- Wmsburg step 20. Do not install the safety rail. It will be used for the picnic table.
- Install the swing beam. Instructions and hardware are in the 7 ft Swing Beam Leg carton (63059-212).
- Install the Picnic Table (SD920-800Q).
- Install the Rock Climber (AH201-102Q).
- Set the ladder and slide as shown above. Check spacing.
 Fasten access brackets to the **inside** of the ladder rails.

- Secure the access ladder using the method shown in step 18 of the Williamsburg instructions.
- Install the slide mount and slide using the method shown in steps 26 and 27 of the Williamsburg instructions
- Install the wall slats in the positions shown above, using the methods from the Williamsburg Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.

WILLIAMSBURG PREMIUM PACK 2

WILL7TPP2-100 Rev B (04-22)