## Creative Plaything/

## CHILDHOOD STARTS HERE

## WILLFSTPP Williamsburg Premium Pack Tower 1

Dimensions of assembled package: 10' 11" wide x 15' 5" deep x 10' 7" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-424 for important safety information.

## Cartons for this Play Set:

- 1 63006-421 Williamsburg Box 1 (Hardware)
- 1 63006-422 Williamsburg Box 2
- 1 63006-423 Williamsburg Box 3
- 1 63006-424 Williamsburg Tent (Hdwre & Instr)
- 1 SH946-102 Access Ladder, 5ft
- 1 8364-400 10ft. Scoop Slide
- 1 AH201-102Q Rock Climbing Wall (Hdwre & Instr)
- 1 SD920-800Q Williamsburg Picnic Table (Hdwre & Instr)
- 1 63090-222 Chain Climber Frame (Hdwre & Instr)
- 1 63089-606 Chain Cargo Net
- 1 SH922-800Q Ramp (Hdwre & Instr)
- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted above.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Wmsbg Step 19. The swing mount is not needed.
- Skip step 20. Do not install the safety rail. It will be used on the picnic table.
- Install the Picnic Table (SD920-800Q).
- Install the Rock Climbing Wall (AH201-102Q) on the side as shown.
- Secure the access ladder to the opposite side of the gym using the method shown in step 18 of the Williamsburg instructions.

- Set the ramp and slide as shown above. Check spacing.
- Install the slide mount and slide using the method shown in steps 26 and 27 of the Williamsburg instructions.
- Install the Ramp (SH922-800Q) next to the slide.
- Assemble the Chain Climber on the back of the gym using the instuctions included in 63090-222.
- Install the wall slats in the postions shown above, using the methods from the Williamsburg Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount the hand grips to the entrance wall slats.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.

WILLIAMSBURG PREMIUM PACK TOWER 1

© Copyright 2018, Creative Playthings

