



Dimensions of assembled package:  
21' 7" wide x 16' 6" deep x 11' 6" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set. Read this sheet and all instructions included with the different parts before assembly. See the Instructions and Owner's Manual included in carton 63062-222 for important safety information.

### Cartons for this Play Set:

1	63062-211	Yorktown 1 (Hardware)
1	63062-222	Yorktown 2 (Instructions)
1	63007-421	Lexington Gym 1 (Hardware)
1	63007-422	Lexington Gym 2
1	63062-301	Yorktown Wood Roof (Hardware)
1	SH946-102	Access Ladder 5ft.
1	SM963-402	Dormer Brown (Hdwre & Instr)
1	SM964-402	Gable Fans (Hdwre & Instr)
2	40456-402	End Panel Assembly
1	40459-402	Double Window Panel
1	40460-402	Door & Window Panel (Hdwre & Instr)
1	63058-202	4 Position Swing Beam
1	63076-303	9ft Beam Legs (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	8364-400	10ft. Scoop Slide
1	SD204-102Q	Lexington Picnic Table (Hdwre & Instr)
1	63093-102	Picnic Adapter (Hdwre & Instr)
1	AH201-102Q	Rock Climbing Wall (Hdwre & Instr)
1	AG943-400	Slide Handle (Hdwre & Instr)
1	AG942-400	Access Ladder Handles (Hdwre & Instr)

- Start by assembling the Yorktown tower. Instructions are in carton 63062-222. Other instructions and hardware are in the cartons noted at left.
- Yorktown step 19. The 9ft Beam will be mounted in the position pictured above. Parallel to the roof.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Install the 9ft Swing Beam. Instructions are in carton 63076-303.
- Review the instructions for the Picnic Table (SD204-102Q) and Picnic Adapter (63093-102). Install the picnic table using the adapter to create a gap for access to the side closest to the swings. The standard installation leaves the gap under the porch but it can be installed with the gap at the back of the tower.
- Install the Rock Climbing Wall (AH201-102Q) in the position shown.
- Secure the access ladder in the position shown using the method shown in step 35 of the Yorktown instructions.
- Fasten Access Ladder Handles (AG942-400) to the Access Ladder.
- Install the slide mount and slide using the method shown in steps 36 and 37 of the Yorktown instructions.
- Install wall slats in the positions shown above, using the methods from the Yorktown instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment. Use entrance slats on either side of the Access Ladder.
- Mount one hand grip to each entrance wall slat.
- Mount the Slide Handle (AG943-400) above the Super Wave Slide.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.