
Yorktown Direct Connect Panel




Farts: 63065-101 Yorktown Direct Connect Panel A 4 33459-402 Panel Board II/I6 x 5 x 49-3/4" B 2 33460-102 Panel End 5/4 x 4 x 21-1/8" C I 33461-402 Narr. Board II/I6 x 2-3/8 x 49-3/4" D 2 33462-102 Panel Cleat 2 x 3 x 23"

SPECIAL NOTES AND INSTRUCTIONS:


If the Direct Connect Slide Adapter is to be used on a Yorktown Gym, it is best to install the Adapter before the Window Panels are installed.

If installing on a pre-assembled Yorktown gym, the Gable Fan, Window Panel and related assemblies adjacent to where the Direct Connect is to be mounted must be removed; they will not be reused. The Double Window Panel and the Door Panel should be removed temporarily for access to the hidden surfaces on the adjacent Posts.



STEP TWO - Panel Ends


Mount the Panel Ends (B) to the outer surface of the Posts shown at right. Rest the Panel Ends against the top of the Platform Support and fasten them using three $\#10 \times 1-5/8$ " Screws each.



STEP THREE - Install Direct Connect Adapter

Assemble the Direct Connect Adapter as indicated in the assembly instructions. Note the three Wall Slats indicated at right are not needed for this assembly. Save the $\#10 \times 1-5/8$ " Screws from these Wall Slats for the next step.

Assembly of the Yorktown gym can be completed at this time



STEP FOUR - Panel Boards

Rest the flat edge of the Narrow Panel Board (C) on the Platform Support. Fasten the Narrow Panel Board to the Panel Cleats and Direct Connect Adapter Frame using four $\#10 \times 1-5/8$ " Screws.

Evenly space the Panel Boards (A) between the Narrow Panel Board and the horizontal support on the Direct Connect Adapter. Fasten each using eight $\#10 \times 1-5/8$ " Screws.

Make sure a Gable Fan is not installed above the Direct Connect Adapter.

