

Creative Playthings®


MODEL # SC 903-800Q
ASSEMBLY MANUAL

SKYBOX PLAYWALLS


ADULT ASSEMBLY REQUIRED.
Intended for Ages 2 to 12 Years.

⚠ CAUTION: Small Parts. Keep from children until fully assembled

PLAYWALL ASSEMBLIES



PARTS




A - (1) 31523-102 End Wall Support - 2 x 4 x 56-3/4"



B - (2) 31524-102 Side Wall Support - 2 x 4 x 47-1/2"




C - (17) 31936-102 Wall Slat - 5/4 x 6 x 20"



(6) 17036-1002 Lag Screw - 5/16 x 2-1/2"



(68) 17020-115 Screw - #10 x 1-5/8" Flat Head Phillips



(6) 17002-206
5/16" Flat Washer




(6) 15081-704
1" Dia. Hole Cap

All hardware on this set is specially coated for corrosion resistance. If non-Creative Playthings hardware is used, it MUST be galvanized or stainless steel.

STEP 1 — FIND PILOT HOLES

There are pre-drilled pilot holes through the gym posts and the Skybox posts. Note the position on the inside face of all posts and the back face of the Skybox posts.

This is where the Wall Supports will mount.




STEP 2 — WALL SUPPORTS

Mount the End Wall Support (A) to the back of the Skybox posts using two 5/16 x 2-1/2" Lag Screws and two 5/16" Flat Washers as shown.


Mount the Side Wall Supports (B) to the inside face of the posts using two 5/16 x 2-1/2" Lag Screws and two 5/16" Flat Washers each, as shown.

Note: Depending on the layout of the play structure, you may want to omit one or more walls to allow access.



STEP 3 — HOLE CAPS

Insert Hole Caps into the counter-bored holes in the Walls Supports to cover the fasteners.




STEP 4 — WALL SLATS

The End Wall Support is slightly higher than the Side Wall Supports. The Walls Slats (C) are to be fastened to the wall supports at the top and Skybox base at the bottom. When placing the wall slats be sure the screw holes overlap the wall supports and skybox base equally.

Secure seven wall slats to the end wall support and Skybox base using four #10 x 1-5/8" screws each. Space them evenly between the posts.

Secure five wall slats to each side wall support and Skybox base using four #10 x 1-5/8" screws each. Space them evenly between the posts.



PLEASE CONSULT YOUR ORIGINAL GYM ASSEMBLY MANUAL FOR MAINTENANCE AND SAFETY INSTRUCTIONS