# Creative Plaything/®

## WILL9WPP11

### CHILDHOOD STARTS HERE

#### WILLIAMSBURG PREMIUM PACK 11



The components of this gym can be combined with others to create different play sets.

This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-445 for important safety information.

#### **Cartons for this Play Set:**

| 1 | 63006-421  | Williamsburg Box 1 Hardware)              |
|---|------------|---|
| 1 | 63006-422  | Williamsburg Box 2                        |
| 1 | 63006-423  | Williamsburg Box 3                        |
| 1 | 63006-445  | Williamsburg Roof (Hdwre & Instr)         |
| 1 | SH946-102  | Access Ladder, 5ft                        |
| 1 | 63058-202  | 4 Position Swing Beam                     |
| 1 | 63060-222  | 9ft Swing Beam Legs (Hdwre & Instr)       |
| 1 | 50546-777  | 3 Swings, 1 Trapeze                       |
| 1 | 15166-400  | 10 ft. Super Wave Slide                   |
| 1 | AG942-400  | Access Ladder Handles (Hdwre & Instr)     |
| 2 | SM964-402  | Gable Fans (Hdwre & Instr)                |
| 2 | SM963-402  | Dormer (Hdwre & Instr)                    |
| 1 | AA918-603  | Chin-up bar (Hdwre & Instr)               |
| 1 | AH201-102Q | Rock Climbing Wall (Hdwre & Instr)        |
| 1 | SD920-800Q | Williamsburg Picnic Table (Hdwre & Instr) |
| 1 | SC908-800Q | Williamsburg Play Floor (Hdwre & Instr)   |
| 1 | 63008-221  | Skybox 1 (Hdwre & Instr)                  |
| 1 | 63008-222  | Skybox 2                                  |
| 1 | SJ926-810  | Skybox Roof (Hdwre & Instr)               |
| 1 | 8400-202   | Spiral Slide, Green (Hardware)            |
| 1 | 63033-102  | Spiral Skybox Mount (Hdwre & Instr)       |
| 1 | AG943-400  | Slide Handle (Hdwre & Instr)              |
| 1 | AG942-400  | Access Ladder Handles (Hdwre & Instr.)    |
|   |            |   |

- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted at left.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Wmsbg step 2. Do not install the sandbox end adjacent to to where the Skybox will be mounted. It will be altered when installing the Skybox.
- Wmsbg step 12. Do not install the back End Wall Support. It will not be needed.
- Skip Wmsbg steps 20 & 21.
- Once the roof, roof supports, and ridge cap are installed, proceed with the Skybox tower.
- Skybox step 2. Do not use the method shown in step 2. Alter the Wmsbg sandbox end and the Skybox sandbox sides as shown at the middle of page 17 in order to fit the Wmsbg play floor.
- Skybox step 11. Use the front posts from The Skybox Roof (SJ926-810) in place of the post extensions.
- Skybox step 17. Wait to install the wall slats on the back, where the Spiral Slide will mount until after installing the Spiral Slide.



- Install the 9ft Swing Beam. Instructions are in carton 63060-222.
- Install the Williamsburg Play Floor (SC908-800Q).
- Install the Skybox Wood Roof (SJ926-810).
- Install the Gable Fans (SM964-402).
- Using a ladder, install the Dormers (SM963-402) in the positions shown. Ladder access may be obstructed by later installations.
- Install the Picnic Table (SD920-800Q).
- Install the Rock Climbing Wall (AH201-102Q) in the postion shown.
- Set the access ladder and slide as shown in the picture on the preceding page. Check spacing.
- Fasten access brackets to the <u>inside</u> of the ladder rails.
   Secure the access ladder using the method shown in step 18 of the Williamsburg instructions.
- Fasten the Access Ladder Handles (AG942-400) to the access ladder.
- Install the slide mount and slide using the method shown in steps 27 and 28 of the Williamsburg instructions.
- · Mount the Spiral Slide to the Skybox in the position shown

- above using instructions included in carton 63033-102. Be sure to mount the slide as far from the swing side of the gym as possible.
- Install wall slats in the postions shown on the front page, using the methods from the Williamsburg instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment. Install the wall slats next to the spiral slide.
- Mount one hand grip to the entrance wall slat between the ladder and the slide on the front of the gym. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Mount the Slide Handle (AG943-400) above the Super Wave Slide.
- Mount the Chin-up bar (AA918-603) in the position shown above.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.

Page 2